


How to install a multiple gang iotty Light Switch as a 3 way switch application (to control a load from two point).



Electrical Installation Requirements


- * A Neutral wire (requires all three AC electrical connections at the wall switch)
- * A single pole light switch (for lights controlled by 2 switches go to section X)
- * The light switch box must be 2 inches deep

WARNING: Electrical wirings should be done by a professional electrician. Incorrect installation is dangerous or illegal. Please call a professional electrician if you are unfamiliar or uncomfortable with electrical work.


Important: it is recommended to use iotty Light Switch for residential and dry indoor locations only.

Remember:

If you are connecting a three gangs switch you won't be able to use **one of the three gangs**. If you are making a 2 ways between two switches, one mechanical and one iotty, you won't be able to control the light from the app, **you will lose all smart functions**. [For the instructions of this case go to www.iotty.com/support]




Turn off the power at the circuit breaker for the switch you are replacing.



Unscrew and disconnect the wires from the old switch using a screw driver.
Remember that you **must** have a *Neutral*

wire to install iotty Light Switch.



Choose which iotty will become i1 and which one i2.

iotty 1 (i1):

Insert the Neutral wire into the terminal screw labeled with N.

Insert the Hot Wire from your wall in the screw terminal labeled with L and in one of the screw terminals of two RLs (in this case RL1 and RL2).

Connect the RLs of i1 inverted with those of i2 (RL1 with the RL2 of i2 and RL2 with the RL1 of i2).


iotty 2 (i2):

Insert the Neutral wire into the terminal screw labeled with N.

Insert the Hot Wire wire from your wall into the screw terminal labeled with L.

Insert in one of the screw terminal of two RLs (in this case RL1 and RL2) the Load you want to control.


Insert in the remaining screw terminal of the RLs involved the inverted wires of i1 (RL1 with the RL2 of i1 and RL2 with the RL1 of i1).



Push all the wires back into the wall box and try to allow as much space for the switch as possible.

Align the two screw terminals and screw in the iotty Light Switch.

Remember to place the two black buttons on the right.




If you want to hide the disabled gang apply on the back of the faceplate the cardstock provided.

You can choose between black or white based on your faceplate color.

Attach your **iotty Light Switch** faceplate starting from one of the two short side.

To remove use a screwdriver to lift the faceplate.



Turn on the power at the circuit breaker.



Download the iotty app from Google Play or the Apple Store and sign in.

Connect to your **iotty Light Switch** wifi [IOTTY_serial-number].

Go to the app and add a new device.

Set the light of each **iotty** (in this case lightl and light2) as Deviator.

